



RAPID REPAIR DESIGN OF TEMPORARY SUPPORT SYSTEMS FOR BRIDGES DAMAGED BY EARTHQUAKES IN THE STATE OF WASHINGTON

APPENDIX A – DESIGN MANUAL

WA-RD 542.2

Final Report
October 2001



**Washington State
Department of Transportation**

Washington State Transportation Commission
Planning and Capital Program Management
in cooperation with:
U.S. DOT - Federal Highway Administration

Final Report
for
Research Project Contract No. T1804-9
Emergency Bridge Repair

**RAPID REPAIR DESIGN OF TEMPORARY SUPPORT SYSTEMS
FOR BRIDGES DAMAGED BY
EARTHQUAKES IN THE STATE OF WASHINGTON**

Appendix A – Design Manual

By

Rafik Y. Itani
Professor

Kenneth J. Fridley
Professor

Luke A. Heath
Graduate Research Assistant

Washington State Transportation Center (TRAC)
Washington State University
Department of Civil and Environmental Engineering
Pullman, WA 99164-2910

Washington State Department of Transportation
Technical Monitor
Mark Szewcik
Bridge Engineer

Prepared for

Washington State Transportation Commission
Department of Transportation

October 2001

**Manual for the Rapid Repair Design of Temporary
Support Systems for Bridges Damaged by
Earthquakes in the State of Washington**



Prepared for the
Washington State Department of Transportation

By the
Department of Civil and Environmental Engineering of
Washington State University

October 29, 2001


Purpose and Scope

This project provides a design manual that includes guidelines and procedures for constructing rapid temporary shoring systems for damaged bridges. This manual will be further integrated into the WSDOT Bridge Design Manual. The designs provided here will be used by the WSDOT bridge officials who will oversee all construction of the temporary shoring systems. This manual could also be implemented into the FEMA handouts for bridge inspection and could be provided to assist other local governments.

WSDOT responsibilities after an earthquake that damages the state transportation system are to insure the safety of the traveling public, protect transportation facilities from further damage, restore traffic on the highway system as quickly and safely as possible, and to maintain a timely and current assessment of the extent of damage and operation status of the transportation system.

The scope of this project deals primarily with the technical aspects of building a rapid pre-engineered shoring system for damaged bridges. Broad criteria were set forth by the WSDOT Bridge and Structures Office to accommodate 75% of all bridges within the state of Washington. The shoring system is to retain heights between 15 to 40-feet.

Flow Chart of Temporary Shoring Construction Plans



*Transverse Cap Details are included **Retighten connections after columns are firmly secured

Conditions of Use

This temporary shoring system is intended to be only a temporary solution. In no case shall the temporary shoring system act as a permanent solution or be in use for more than one year from the time of erection. Any changes to the manual must be documented and approved by a licensed Washington State Civil Engineer. The temporary shoring system is not intended to withstand after-shocks that follow the initial seismic event. This manual may be used only under the following conditions:

- Any chosen option in the flow chart must be followed through completely for each damaged column (or row of columns) such that there is no mixing and matching of flow chart options.
- Columns may not be subjected to any lateral earth pressures.
- Each damaged column must support its self-weight and the superstructure must maintain its integrity.
- All shoring foundations must be placed upon level ground.
- No vehicular traffic is allowed to traverse the damaged bridge without the prior consent from WSDOT. Temporary shoring must be in place and approved by the engineer of record before traffic may traverse the damaged bridge.
- Vehicular travel must be regulated in such a manner as to limit the effects from super-elevation, bridge curvature, acceleration and deceleration of vehicles. The suggested construction speed across the damaged bridge is to be 15 mph.
- Upon each after-shock, the damaged bridge and the temporary shoring system shall be thoroughly checked over to assess the integrity of the structure and the shoring system. Access to the road should be closed during this time until officials deem the bridge safe to open again to the public. WSDOT shall be notified of any signs of failure and the bridge shall be closed immediately.
- The depicted bridges in the manual represent 75% of all bridges within the State of Washington. The shoring system is only applicable if the damaged bridge's geometry is the same or smaller than the bridge geometry shown in the manual.
- Jacking struts with hydraulic jacks will be used to pre-load the shoring system, such that bridge is shored properly. Steel or wood wedges shall be used to abut the temporary shoring system to the bridge. Shoring columns closest to the damaged columns or support will be preloaded more to distribute load equally with the outer most shoring columns.
- No welding is to take place on the existing damaged steel plate girder bridge.

Explanation of the Outline of Temporary Shoring Construction Plans

The flow chart is an aide for the rapid construction of temporary shoring systems for the Washington State Department of Transportation (WSDOT). This manual is designed to cover 75% of all bridges within the State of Washington in the event of a catastrophic earthquake. The following is an explanation of the flowchart.

The first step is to read the Conditions of Use, which provide limits and necessary information for which the shoring systems are valid. The second step is to determine the materials, either steel or wood, that the shoring columns will be comprised of. The initial overview drawings include design stresses, assumptions, criteria, and a general shoring layout. Identifying the type of bridge is the third step, either prestressed concrete girder bridge, concrete box girder bridge, or steel plate girder bridge. Please note, that the wood column shoring tower must be used for the prestressed girder bridges. Each bridge type has a drawing with construction details for the layout of the transverse cap, columns, cross bracing, connections, etc. The overview drawing is to be the main reference for assembling the temporary shoring tower for the particular bridge type. Finally, the footings for the shoring tower are the last general construction detail mentioned in the flowchart. Specific details are incorporated throughout the manual on the final drawing sheet.

Use of these shoring systems is contingent upon a safe working environment and a prior investigation of the damaged bridge. A suitable site for the footings and the shoring columns must also be determined, preferably within 10-feet of the damaged columns and 5-feet for simply supported bridge spans. The footings shall be placed upon level ground. Jacking struts with hydraulic jacks shall be used to pre-load the shoring system, such that bridge is shored properly. Steel or wood wedges shall be used to abut the temporary shoring system to the bridge. All bolted connections, after the jacking struts are removed, shall be re-tightened to complete the construction of the shoring systems.

The shoring system shall be checked and approved by a WSDOT official before traffic is allowed to travel across the bridge. The temporary shoring shall be monitored closely along with the bridge after the completion of the shoring system. WSDOT shall be notified of any signs of failure and the bridge shall be closed immediately.

Following these outlined steps will ensure consistency and safety for the construction crew and the public. The Department of Transportation Bridge and Structure's Office shall address any questions about the construction of the temporary shoring systems.

Wood Shoring Column Assumptions and Notes:

Shoring columns shall be 12" by 12" or larger timbers or by 12" minimum diameter round piles. Round columns must conform to ASTM Standard D3200

All cross bracing and lateral bracing members are to be 4" by 8" or larger Dimensional Lumber

All Wood members are to be Hem-Fir or Douglas Fir-Larch and No 2 or better Sill Beams and Transverse Caps shall be either HP12X53 or HP14X89, steel shall be A36.

Allowable Design Stresses

Wood:

$F_c = 1000$ psi

$E = 1,300,000$ psi

$F_v = 110$ psi

$F_t = 600$ psi

$F_c(\text{perpendicular}) = 400$ psi

$F_b = 1100$ psi

Steel: $F_y = 36$ ksi

$E = 29,000$ ksi

Concrete: $F_c = 4000$ psi

Soil: Allowable Bearing ≈ 3000 psi

Design Loads

Dead Load: Concrete = 160 pcf

Steel = 490 pcf

Live Load: AASHTO HS20-44

Each wood column is designed for an axial load of 17 kips and cross bracing designed for 2% of the axial load applied horizontally.

Shoring Dimensions

- Shoring column spacing along width of bridge
 - Concrete Box Girder = 5'9"
 - Steel Plate Girder Bridge and Prestressed Girder Bridge, columns will be placed directly under existing girders

** Height of shoring column


Column height shall be 15' to 40'

*** Shoring column spacing along length of bridge

Concrete Box Girder = 8'

Steel Plate Girder Bridge = 8'

Prestressed Girder Bridge = 8'



Section A-A of Shoring Tower along Bridge Width

Drawing Not to Scale

Setup of Shoring Tower along Bridge Length

Drawing Not to Scale

Washington State University

Professional Engineer's License

Temporary Shoring Project

Overview of Wood Column and Cross Bracing Setup

Scale: Not to scale

Date: August 15, 2001

Page 1

of 11

Name

Date

LAH 7/01


Designed By:

LAH 7/01


Drawn By:

LAH 7/01

Checked By:



Concrete Prestressed Bridge Column and Transverse Cap
Layout for Wood Column Shoring System



Typical Column Overpass Failure
Drawing not to scale

- Max Allowable Span Length A = 140'
- Max Allowable Span Length B = 140'
- Allowable Shoring Height is 15' to 40'

Disclaimer: This Shoring System is only applicable if the existing damaged bridge has the same geometry or smaller.

**Washington
State University**

Professional Engineer's License

**Temporary
Shoring Project**

Wood Tower Layout for Prestressed Girder Bridges

Page **2**

of **11**

Date: August 15, 2001

Scale: Not to Scale

Notes:

Lateral Bracing will span every 5 feet along shoring columns

Shoring columns shall be 12" by 12" or larger Timbers or by 12" minimum diameter round piles Round columns must conform to ASTM Standard D3200

All wood members shall be Hem-Fir or Douglas Fir-Larch and No. 2 or better



All Steel Shoring Members (Transverse Cap, Sill Beam, or Corbels) shall be either HP12X53 or HP14X89, steel shall be A36.

The shoring system shall be placed within 10 feet of the failed column, except for simply supported spans which must be within 5 feet.

All shoring columns shall be placed vertically and plumb. All Footings shall be placed upon level ground.

Number of 12" by 12" or 12" Min. Diameter wood shoring columns needed per side of damaged column Concrete Prestressed Girder Bridge = 16 (2 columns per concrete Prestressed girder)

Concrete Prestressed Girder Bridge has 3 Lanes



Disclaimer: This Shoring System is only applicable if the existing damaged bridge has the same geometry or smaller.

Washington State University

Designed By:	LAH	Date	7/01
Drawn By:	LAH		7/01
Checked By:			

Professional Engineer's License

Temporary Shoring Project

Wood Tower Layout for Concrete Box Girder Bridges


Page **3** of **11**

Date: August 15, 2001


Scale: Not to Scale

Notes:

- Lateral Bracing will span every 5 feet along shoring columns
- Shoring columns shall be 12" by 12" or larger timbers or by 12" minimum diameter round piles. Round columns must conform to ASTM Standard D3200
- All wood members shall be Hem-Fir or Douglas Fir-Larch and No 2 or better.
- All Steel Shoring Members (Transverse Cap, Sill Beam, or Corbels) shall be either HP12X53 or HP14X89, steel shall be A36.
- The depicted Concrete Box Girder Bridge has 4 Lanes
- The shoring system shall be placed within 10 feet of the failed column, except for simply supported spans which must be within 5 feet.
- All shoring columns shall be placed vertically and plumb. All Footings shall be placed upon level ground.
- Total Number of 12" by 12" or 12" Min. Diameter wood shoring columns needed per side of damaged column Concrete Box Girder Bridge= 20
- For smaller sized Box Girders, maintain shown spacing between shoring columns.



Steel Plate Girder Bridge Column and Transverse Cap Layout for Wood Column Shoring System



*Max Allowable Span Length A = 133.5'
 Max Allowable Span Length B = 107.5'
 ** Allowable Shoring Height is 15' to 40'


Disclaimer: This Shoring System is only applicable if the existing damaged bridge has the same geometry or smaller.

Notes:

- Lateral Bracing will span every 5 feet along shoring columns
- Shoring columns shall be 12" by 12" or larger timbers or by 12" minimum diameter round piles.
- Round columns must conform to ASTM Standard D3200
- All wood members shall be Hem-Fir or Douglas Fir-Larch and No. 2 or better.
- All steel shoring members (Transverse Cap, Sill Beam, or Corbels) shall be either HP12X53 or HP14X89, steel shall be A36.
- The shoring system shall be placed within 10 feet of the failed column, except for simply supported spans which must be within 5 feet.
- All shoring columns shall be placed vertically and plumb. All footings shall be placed upon level ground.
- Number of 12" by 12" or 12" Min. Diameter wood shoring columns needed per side of damaged column for Steel Plate Girder Bridge = 6 (2 wood columns per steel plate girder)
- Two full length, steel 6x6x1/2 angle stiffeners shall be placed at each column on the steel plate girder bridge and bolted. Now welding is permitted to the superstructure.
- The depicted bridge has a 2 lane capacity


Washington State University	Professional Engineer's License	Temporary Shoring Project	Wood Tower Layout for Steel Plate Girder Bridges		Page 4
			Scale: Not to Scale	Date: August 15, 2001	of 11
Designed By: LAH	Date: 7/01	Checked By: LAH			
Drawn By: LAH	Date: 7/01	Checked By:			

Notes:
Footings will be made up of 12" by 12" Timbers
Wood members shall be Hem-Fir or Douglas Fir-Larch and No. 2 or better.
Sill Beams may be either HP12X53 or HP14X89, steel shall be A36.
Footing members may be continuous provided that the members meet the length and size criteria for each column as depicted in this drawing.



Layout of Timber Shoring Foundation along Bridge Width


- Sill Beam = HP12X53 or HP14X89
Footings = 12" by 12"
• Spacing of Columns
Prestressed Girder Bridge = 6'2"
Steel Plate Girder Bridge = 11'3"
Concrete Box Girder Bridge = 5'9"
• Number of 12" by 12" Footings
Prestressed Girder Bridge = 6
Steel Plate Girder Bridge = 6
Concrete Box Girder = 6




Layout of Typical Shoring Foundation along Bridge Length

- Sill Beam = HP12X53 or HP14X89
• Length of 12" by 12" Footings
Prestressed Girder Bridge = 8'
Steel Plate Girder Bridge = 8'
Concrete Box Girder = 8'


Washington State University	Professional Engineer's License		Timber Foundation Layout for Wood Tower		Page 5
	Designed By:	Name	Date	Scale: Not to Scale	of 11
	Drawn By:	LAH	7/01		
Checked By:		LAH	7/01	Date: August 15, 2001	




1 Side View of Timber Shoring Pole Connection
This diagram is applicable for both the Transverse cap and sill beam




2 Top View of Timber Shoring Pole Steel Cap Connection
This diagram is applicable for both the Transverse cap and sill beam




3 Double Plate Bearing Stiffeners for the Steel Plate Girder at Shoring Column
Bearing Stiffeners shall be A36 steel and coped to clear welds.
If existing longitudinal stiffeners are encountered, the angle section can be terminated to clear the longitudinal stiffener and then resumed again.
Steel angles are to bear on the bottom flange of steel girder. Provide 1 inch gap between angles and top flange of the steel girder.
For connection detail to shoring system, see Diagram 8




4 Side View of Timber Shoring Column Connection
This diagram is applicable for both the Transverse cap and sill beam



5 Top View of Timber Shoring Column Connection
This diagram is applicable for both the Transverse cap and sill beam



6 Plan View of Steel Girder to HP14X89 Connection
No welding is permitted to the Steel Plate Girder Bridge.
Two 2000 lb clamps are to be placed at each connection as indicated by the symbol of 6



7 Typical Wood Shoring Connection with 2 Bolts
Cross-bracing member to be 4 inch by 8 inch or larger.
Wood Column to be 12 inch by 12 inch or 12 inch Minimum Diameter Pole.
Horizontal cross-bracing members are allowed to use 1 inch diameter bolts.
All diagonal cross-bracing members shall use 1 inch diameter bolts and not exceed 45 degrees.
Bolts are to be ASTM A307

Washington
State University

Professional Engineer's License

Temporary
Shoring Project

Miscellaneous Details for Wood Tower


Page 6

Scale: Not to Scale

Date: August 15, 2001


of 11

Notes:
All steel is to be $F_y = 36$ ksi or greater.
The transverse beam is to be A36 HP14X89.
All Column Base Plates are to be welded to sill and transverse beams.
Concrete Box Girder Bridge Details has 4 Lanes.
The shoring system shall be placed within 10 feet of the failed column, except for simply supported spans which must be within 5 feet.
All shoring columns shall be placed vertically and plumb. Footings shall be placed upon level ground.
Number of steel shoring columns needed per side of damaged column for the Concrete Box Girder Bridge is 10.
For smaller sized box girders, maintain the same number of columns and layout.



Concrete Box Girder Bridge Layout for all Steel Shoring System

- If the As-Built Dimensions are known, place the shoring columns directly beneath the webs, otherwise space columns at distance of 10 feet and center sets of shoring towers about the bottom of the box girder.




Disclaimer: This Shoring System is only applicable if the existing damaged bridge has the same geometry or smaller.


*Allowable Span Length A = 140'
Allowable Span Length B = 110'
** Allowable Shoring Height is 15' to 40'

Typical Column Overpass Failure
Drawing not to scale

Washington State University		Temporary Shoring Project		Steel Tower Layout for Concrete Box Girder Bridges		Page 8 of 11
Designed By:	LAH	Date	7/01	Scale: Not to Scale		Date: August 15, 2001
Drawn By:	LAH	Checked By:	7/01			



Steel Plate Girder Bridge Layout for all Steel Shoring System
Drawing Not to Scale



Typical Column Overpass Failure
Drawing not to scale

*Allowable Span Length A = 133.5'
Allowable Span Length B = 107.5'
** Allowable Shoring Height is 15' to 40'


Notes:

- All steel is to be $F_y = 36$ ksi or greater
- Column Base Plates will be secured to prevent lateral or vertical movement of the columns
- Bearing Stiffeners are to be placed concentrically with each column shoring support as shown
- Steel Plate Girder Bridge has 2 Lanes
- The shoring system shall be placed within 10 feet of the failed column, except for simply supported spans which must be within 5 feet.
- All shoring columns shall be placed vertically and plumb. Footings shall be placed upon level ground.
- Number of steel shoring columns needed per side of damaged column for the Steel Plate Girder Bridge is 6 (2 columns per girder)

Disclaimer: This Shoring System is only applicable if the existing damaged bridge has the same geometry or smaller.


Washington State University	Name LAH	Date 7/01	Professional Engineer's License	Temporary Shoring Project	Steel Tower Layout for Steel Plate Girder Bridges	Page 9
	Designed By: LAH	Drawn By: LAH			Scale: Not to Scale	of 11

Date: August 15, 2001



1/10 Plan View of Steel Tower Foundation Layout

Sill Beam = HP14X89
Corbel = HP14X89 or HP12X53
Steel Plate = 5' by 10' by 1"



2/10 Cross Section of Steel Shoring Tower Foundation Layout

Place 10 full length 12 by 12 underneath the steel plate. All wood members are to be Hem-Fir or Douglas Fir-Larch and No. 2 or better.

**Washington
State University**

Professional Engineer's License

Designed By:	Name	Date
Drawn By:	LAH	7/01
Checked By:	LAH	7/01

**Temporary
Shoring Project**


Steel Foundation Layout for Steel Tower

Scale: Not to Scale


Date: August 15, 2001

Page 10


of 11




1
11
Column Base Plate Details
Dimensions for "a"
HP12X53 a=14"
HP14X89 a=16"
Base Plate Thickness = 1"
Weld perimeter of H-Pile and
column plate




2
11
Cross Bracing Column Connections
for Weak Axis Bending




4
11
Cross Bracing Column Connections
for Strong Axis Bending
- All welds are 1/4" E70 Fillet Welds
- Steel Shoring Columns are HP12X53 or HP14X89
- Max angle of Steel Angle is 45°
- Weld full lengths of gusset angle legs to column
flanges as depicted in diagram 5 of this page.
- All cross bracing members are to be welded in
the same manner as depicted in diagram 2 of this
page.




3
11
Double Plate Bearing Stiffeners for the Steel Plate
Girder of Shoring Column
- Bearing Stiffeners shall be A36 steel and coped.
- If existing longitudinal stiffeners are encountered,
the angle section can be terminated to clear the
longitudinal stiffener and then resumed again.
- The steel angles are to bear on the bottom
flange of the steel girder. Cope angles to clear
welds. Provide 1" gap between angles and top
flange of the steel girder.
- For Steel Plate Girder to Shoring System
Connection see Diagram 7



5
11
Gusset Angle Connection Details



7
11
Plan View of Steel Girder to HP14X89 Connection
- No welding is permitted to the Steel
Plate Girder Bridge
- Two 2000 lb clamps are to be placed
at each connection as indicated by the
symbol of @



6
11
Bearing Stiffeners for HP12X53 or HP14X89
Stiffener Size:
HP12X53 use 4" by 1/2"
HP14X89 use 6" by 1/2"
Stiffeners may also be coped
with 1/2" fillets and are required
at each point load

